



## ACURA CL (1997)

PART NUMBER: **AC-56-97**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** Hook tool, 8mm socket, ratchet, and extension, #2 Phillips screwdriver, 5/64" drill bit and drill, marking pen, small coarse file, masking tape.

**PARTS INCLUDED:** Pro.Fit VSM™, one #8x3/8" screw and instructions.

**LOCATION:** To the right of the radio.

### STEP 1.

Begin by opening cubby hole door located below the radio. Insert hook tool in cubby hole at right side of bezel between bezel and felt liner. Pull toward you to release right clip. Repeat on left side. Insert hook tool in the upper left corner of radio and pull toward you releasing one (1) top clip. Grasp the bezel with hands and pull toward you releasing two (2) bottom clips. Disconnect all wiring and set bezel aside.



### STEP 2.

Locate and remove bolt to the right of the radio using your 8mm socket, extension and ratchet. Align Pro.Fit VSM™ with bolt hole. Insert and tighten factory bolt. Using the remaining hole in the Pro.Fit VSM™ as a guide, drill a pilot hole with your 5/64" drill bit and drill. Insert provided screw and tighten with #2 Phillips screwdriver. Put bezel back into place. With marking pen, mark the area where a rib on the bezel must be filed in order for the bezel to fit flush. **NOTE: This area is where the rib on the bezel meets the 11™.** Pull the bezel out and cover the area to be filed with masking tape. **NOTE: This is to protect the rest of the bezel from damage.** With a small coarse file, remove about 1/16" of material off of the marked area of bezel.




### STEP 3.

Reconnect all wiring to bezel and put bezel back into place securing all clips. Attach hang-up cup onto Pro.Fit VSM™.



This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2003

<p><b>VIEW INSTRUCTIONS &amp; UPDATES</b> ONLINE @ <a href="http://WWW.PRO-FIT-INTL.COM">WWW.PRO-FIT-INTL.COM</a></p>
---