



**AUDI 100 (1992-95) AUDI 200 (1992-94)
AUDI A6 QUATTRO (1996-97)**

PART NUMBER: AU-52-92

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: One 8mm socket and driver, one hook tool.

PARTS INCLUDED: Pro.Fit VSM® and instructions

LOCATION: To the right of the switch for the passenger heated seat control.

STEP 1.

Begin by removing the blank switch cover to the right of the passenger heated seat control. Carefully insert the hook tool behind the blank cover. Pull toward you to release two clips that hold the cover in place. Set the cover aside.



STEP 2.

Using the 8mm socket and driver, remove the two (2) 8mm hex head screws which were concealed behind the cover. Set the screws aside. Attach the phone holder to the Pro.Fit VSM®.



STEP 3.

Position the Pro.Fit VSM® over the two (2) screw holes. Replace the two (2) factory screws and tighten. Carefully replace the blank cover by snapping the top and bottom clips into position.



This completes the installation of your Pro.Fit VSM®.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Installation Difficulty



© Pro.Fit International, Eagan, MN 2003

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**