



BUICK LESABRE & PARK AVENUE (1992-94) OLDSMOBILE 88 & NINETY EIGHT (1992-93)

PART NUMBER: **BK-50-92**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 9/32" socket with flex driver.

PARTS INCLUDED: Pro.Fit VSM®, instructions.

LOCATION: To the right side of ashtray.

STEP 1.

Using 9/32" socket & flex driver open ash tray and remove two (2) factory screws at right side of ash tray assembly.



STEP 2.

Attach phone hang-up cup to Pro.Fit VSM®. Position mount over screw holes on right side of ash tray. Replace the two (2) factory screws and tighten.



STEP 3.

Minor adjustments can be made to change the angle of phone by using a couple of flat washers between the hang-up cup and Pro.Fit VSM®.



This completes the installation of your Pro.Fit VSM®.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

