



INSTALLATION INSTRUCTIONS

BUICK REGAL (1996-97)

PART NUMBER: BK-52-96

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 9/32" socket and ratchet.

PARTS INCLUDED: **Pro.Fit VSM™** and instructions.

LOCATION: Right side of temperature control.

STEP 1.

Begin by removing the dash trim bezel by grasping the left side of the bezel and pulling outward. Work your way carefully toward the radio. As you do this, you will be releasing eight (8) clips: three (3) along the top; four (4) along the bottom; and one (1) in the middle. Set trim bezel aside.



STEP 2.

Locate and remove the bolt on the right side of the temperature control box. Place **Pro.Fit VSM™** behind the control box, aligning centering pin and bolt hole. Reinsert and tighten factory bolt.



STEP 3.

Replace radio trim bezel. Install hang-up cup onto **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com