



INSTALLATION INSTRUCTIONS



BMW 325i (COUPE & SEDAN ONLY) (1992 - 95)

PART NUMBER: BM-50-92

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 2 Phillips screw driver.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: To the right side of climate control computer.

STEP 1.

Begin by removing the climate control module. Insert hand, palm up, into compartment below module. Insert finger into hole in top of compartment, pushing up and out on module. The module will snap out. Lay to left side of console (**DO NOT disconnect wiring.**) Remove compartment by inserting finger, pulling up and out. This will pivot up from shifter console. Set aside.

STEP 2.

Remove screw inside dash housing on right and push bracket to the rear. Remove screw holding right side trim panel. This allows panel on right side to open slightly to insert **Pro.Fit VSM™**.

STEP 3.

Remove screw at upper right corner of trim panel. Attach phone hang-up cup to **Pro.Fit VSM™**. From the right side of console, slide **Pro.Fit VSM™** through the seam of the right trim panel. Position in relief cut out. The **Pro.Fit VSM™** should be positioned on top of trim bracket. Replace Phillips screw and tighten.

STEP 4.

Replace the other screw in housing bracket. Replace upper trim screw, put compartment back into place, and replace climate control module.

This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
Web Address: www.pro-fit-intl.com