



BMW

**323i Sedan (1999-2001), 325Xi (2001-2003)
328Ci (2000-2005), 328i Sedan (1999-2001)
330xi (2001-2005), 330Ci (2001-2005)
M-Series (2001-2006)**

PART NUMBER: BM-50-99

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Medium-size flat head screwdriver, 10mm socket & driver.

PARTS INCLUDED: **Pro.Fit VSM®**, instructions.

LOCATION: To the right of the radio/climate control.

STEP 1.

Locate the dash trim piece that is above the glove box door and below the airbag. Locate a seam where this trim piece meets the trim piece that surrounds the radio. Insert the flathead screwdriver underneath the trim piece approximately two inches to the right of the seam. **Carefully** pry toward you releasing one compression style clip. Continue working the trim piece loose over to the passenger side door, releasing three more clips. Set the trim piece aside.



STEP 2.

Grasp the trim piece that surrounds the radio and carefully pull it toward you releasing one small plastic clip just above the radio. Insert the flat head screwdriver underneath this trim piece just to the right of the steering wheel. **Carefully** pry toward you to release one compression style clip. Set trim piece aside.



STEP 3.

Using the 10mm socket and driver, locate and remove the 10mm hex nut that is to the right of the radio. Place the **Pro.Fit VSM®** over the stud for the hex nut. Replace the nut and tighten.



STEP 4.

Re-assemble the dash in reverse order securing all clips. Install the the phone holder onto the **Pro.Fit VSM®**.

This completes the installation of your **Pro.Fit VSM®**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit Legend™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Installation Difficulty



Simple

Advanced

© **Pro.Fit International**, Eagan, MN 2006

VIEW INSTRUCTIONS & UPDATES

ONLINE @

WWW.PRO-FIT-INTL.COM