



Chevrolet Silverado LT 1500, 2500, 3500 (2007-2009)
GMC Sierra SLE 1500, 2500, 3500 (2007-2011)



PART NUMBER: CV-72-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" drill bit and drill, T15 torque bit, 7 mm socket and wrench, Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two # 8 x 1/2" screws

LOCATION: Right of air vent

STEP 1. Between the upper and lower glove box is a strip of plastic trim held in place by four (4) clips that must first be removed. Beginning on the left side of the trim piece, place the pointed end of the DTT behind the trim piece. Carefully twist the DTT in order to release the trim clips from left to right until all four (4) clips have been removed. Set trim piece aside.

STEP 2. Remove the upper glove box compartment by first removing the two 7 mm bolts holding the bottom portion of the upper glove box compartment in place. Next, using a T15 torque bit, remove the two torque screws located in the upper right and left hand portions of the upper glove box. Place the DTT in the upper left hand corner of the glove box in the space between the glove box and the dash molding. Four (4) clips hold the upper glove box in place. Carefully pop the first clip in the upper left hand corner and work the DTT in a clockwise rotation around the glove box until all four (4) clips have been removed. Carefully place the upper glove box aside.

STEP 3. Place the VSM G3 in place as in picture two (Note: in the 2500 and 3500 series pickups, there may be a piece of foam over this particular area which must be removed in order to allow the mount to be placed correctly). Using a marking pen, mark the two positioning holes using the VSM G3 as a guide. Next use the 5/64" drill bit and carefully drill out the pilot holes over the marked area. Place the VSM G3 over the two pilot holes as flush up against the dash as possible. Using the two provided screws, carefully secure the VSM G3 in place. Once the VSM G3 is secured and in place, begin placing the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ● ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com