



DODGE INTREPID (1998-2003)

PART NUMBER: **DG-50-98**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: One #2 Phillips screwdriver, one (1) hook tool.

PARTS INCLUDED: **Pro.Fit** custom mount, instructions.

LOCATION: To the right of the radio.

STEP 1. Begin by applying the parking brake. Turn the ignition switch to the accessory position and shift the transmission into the **neutral** position. Insert the hook tool behind the **left rear corner** of the bezel that surrounds the shifter. This bezel also has the ashtray integrated into it. Pull upward to release one (1) clip. Insert the hook tool behind the right lower corner of the bezel and pull upward to release one (1) more clip. Grasp bezel and pull upward and towards rear of the vehicle simultaneously to release two (2) more clips located on the left and right sides of bezel. When the bezel is loose, let it rest just in front of the center armrest. **NOTE: There is no need to remove the shifter knob.**

STEP 2. Remove the bezel that surrounds the radio and cubby hole. **NOTE: The climate control is integrated into the bezel and will stay attached to the bezel when removed.** Insert the hook tool behind the lower right corner of bezel just below the cubby hole and pull toward you releasing one (1) clip. Do the same on the lower left side releasing one (1) more clip. Insert hook tool behind bezel in the top right corner of cubby hole. Pull toward you to release one (1) clip. Do the same in the upper left corner of cubby hole releasing one (1) clip. Insert the hook tool behind the upper right corner of bezel and pull toward you to release top right clip. Grasp the bezel and pull toward you working the bezel loose over to the steering column releasing two (2) more clips. Once the bezel is loose disconnect all wiring to the climate control. Set bezel aside.

STEP 3. Locate and remove four (4) screws that hold the radio in place using your #2 Phillips screwdriver. Set screws aside. Pull the radio out just enough to slide the **Pro.Fit VSM®** behind the right side of the radio mounting bracket. Align all holes and slide radio back into place. Replace factory screws and tighten. Reassemble the dash in reverse order securing all clips and wiring.

STEP 4. Install hang-up cup onto the **Pro.Fit VSM®**. This completes the installation of your **Pro.Fit VSM®**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM®**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

