



INSTALLATION INSTRUCTIONS
CHRYSLER LHS (1994-97)
CHRYSLER NEW YORKER (1994-96)

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PART NUMBER: DG-51-94

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 3/8" Socket and driver, small Exacto knife, hook tool.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by removing the trim bezel surrounding the radio. Insert the hook tool behind the bezel in the upper right corner of the bezel. Pull toward you to release top right clip. Perform this same action in all four corners of the bezel releasing a total of six clips. Set the bezel aside.



STEP 2.

Attach the phone holder to the **Pro.Fit VSM™**. Using the 3/8" socket and driver, locate and remove the screw to the right of the radio. Position **Pro.Fit VSM™** over the screw hole. Replace and tighten the factory screw.



STEP 3.

Locate a plastic tab on the upper inside part of the trim bezel. **NOTE: Always use extreme caution when working with plastic dash parts. Carefully** remove this tab using the Exacto knife, cutting it off at its base.



STEP 4

Re-install the trim bezel securing all six (6) clips.

This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com