



INSTALLATION INSTRUCTIONS
CHRYSLER CONCORDE (All) (1998-2003)
CHRYSLER CONCORDE (Except LXI) (2004)

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PART NUMBER: DG-57-98

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tool.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by applying the emergency brake. Turn the ignition to the **(on)** position and place the transmission into low gear. Remove the trim bezel that surrounds the radio. This bezel also has the climate control **integrated** into it. The bezel has a total of eight (8) clips holding it in place. Insert the hook tool behind the upper right corner of the trim bezel and pull toward you to release the top right clip. Perform the same action in the upper left corner releasing top left clip. Perform this same action in the lower right and lower left corners of the radio releasing two (2) clips. Insert the hook tool behind the bezel in the lower right and left corners of the cubby hole just below the radio. Pull toward you to release two (2) clips. Remove ashtray and set it aside. Grasp the lower section of the bezel down by the ashtray and pull toward you to release two (2) clips that are located behind the ashtray cavity. **Disconnect all wiring to the bezel and set the bezel aside.**



STEP 2.

Using the #2 Phillips screwdriver, locate and remove four (4) screws that hold the radio in place. Set screws aside. Slide the radio out just far enough to get the **Pro.Fit VSM™** behind the right side of the radio mounting bracket. Align the holes in the **Pro.Fit VSM™** with the holes in the radio mounting bracket. Slide the radio back into place and tighten all four (4) factory screws that hold the radio in place.

STEP 3.

Re-assemble the dash in reverse order securing all wiring and clips. Install the phone holder onto the **Pro.Fit VSM™**.

STEP 4.

This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 612-688-3588 or 800-388-0073 Fx: 612-688-9876

Web Address: www.pro-fit-intl.com

