



Chevrolet Avalanche (2007-2009)
Chevrolet Silverado LTZ 1500,2500,3500 (2007-2009)
Chevrolet Suburban & Tahoe (2007-2009)
GMC Yukon (2007-2009)
GMC Sierra SLT 1500, 2500, 3500 (2007-2009)



PART NUMBER: DG-71-05-L

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: #2 Phillips screwdriver, Dash Trim Removal Tool (DM-40-22), 5/64" drill bit and drill

PARTS INCLUDED: Pro.Fit Legend, instructions, two (2) #8 x 1/2" screws

LOCATION: Right of radio or Left of radio

STEP 1.

Insert dash trim tool behind upper right corner of radio trim bezel. **Photo 1.** Pry gently to release retainer clip. Work tool clockwise around bezel releasing four (4) clips on right side and four (4) on left. Lift bezel off and set aside.



STEP 2.

Align the Pro.Fit Legend between the center retainer clips on either the left or right side of the radio. **Photo 2 or Photo 3.** Using the Legend as a guide, mark the location of two (2) screw holes. Set Legend aside. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the Legend over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.



STEP 3. Re-assemble the dash in reverse order. This completes the installation of your Legend.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Legend™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced