



INSTALLATION INSTRUCTIONS
DODGE DAKOTA PICKUP (1992-96)
PART NUMBER: DG-71-92

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, one (1) T-20 Torx driver.

PARTS INCLUDED: **Pro.Fit** custom mount, instructions.

LOCATION: To the right of the cigarette lighter.

STEP 1.

Begin by removing the cowling that is located just below the steering column. Using your Phillips screwdriver remove two (2) Phillips screws that hold this cowling in place, Both screws are located towards the bottom of the cowling on the right and left of the steering column. Set screws aside and Let the cowling hang.

STEP 2.

Using your Torx driver, remove eight (8) Torx screws that hold the dash trim Bezel in place. There are four (4) Torx screws on each side of the steering wheel. Grasp the trim bezel and remove it from the dash. Set bezel aside.

STEP 3.

Remove two (2) Phillips screws that hold the cigarette lighter in place. Pull the lighter out towards you about 3/4". Position the **Pro.Fit VSM™** behind the lighter, aligning the screw holes. Place the cigarette lighter back into position. Insert the factory screws and tighten.

STEP 4.

Reinstall the dash in reverse order securing all screws. Install your hang-up cup onto the **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **Pro.Fit International**, Eagan, MN 2003