



INSTALLATION INSTRUCTIONS
DODGE DURANGO (1998-2000)
DODGE DAKOTA PICKUP (1997-2000)
DODGE DAKOTA QUAD CAB (2000)
(A/T Only)

**VIEW INSTRUCTIONS & UPDATES
 ONLINE @
 WWW.PRO-FIT-INTL.COM**

PART NUMBER: **DG-71-98**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, 5/64" drill bit, drill, marking pen.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions, two (2) #10x5/8" screws.

LOCATION: Lower right corner of radio, below the radio.

STEP 1.

Begin by removing the dash cluster trim bezel. Do this by grasping the top of the trim bezel and pull **carefully**, releasing top clips. A total of eight (8) clips will be released. [Locations of clips are: three (3) on top, four (4) on bottom, and one (1) on the right side of the bezel.] **Disconnect all wiring to the bezel.** Set bezel aside.

STEP 2.

Locate a flat spot just below the lower right corner of the radio and to the left of the lower right bezel clip hole. Place **Pro.Fit VSM™** over this flat spot. Using the two (2) holes in the **Pro.Fit VSM™** as a guide, mark two spots for pilot holes with a marking pen and set mount aside. Using your drill and 5/64" drill bit, drill two (2) pilot holes.

STEP 3.

Place and align the **Pro.Fit VSM™** over the two pilot holes. Insert the two (2) screws provided and tighten with your #2 Phillips screwdriver.

STEP 4.

Replace the dash cluster trim bezel securing all clips and wiring. Install hang-up cup onto **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



Pictures are of a 1998 Dodge Dakota.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **Pro.Fit International**, Eagan, MN 2003