



DODGE RAM CARGO VAN (1998-2004)

PART NUMBER: **DG-90-98**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tool, 5/64" drill bit and drill, marking pen.

PARTS INCLUDED: Pro.Fit VSM™, instructions, three #8x1/2"

LOCATION: To the right of the far right air vent that is integrated into the bezel.

STEP 1.

Begin by removing the bezel that surrounds the radio, climate control, and instrument cluster. To do this insert the hook tool behind the lower right corner of the bezel just below the air vent. Carefully pull toward you to release the first clip. Perform this same action in the upper right corner of the bezel releasing the top right clip. Grasp the bezel just above the cigarette lighter. Carefully pull toward you releasing a series of clips that hold the top of the bezel and extends over to the driver's side door. Continue to work the bottom clips loose all the way over to the right of the climate control. There are a total of nine clips holding the bezel in place. Remove the bezel from the dash and set it aside.



STEP 2.

Inside the air vent cavity on the right side, locate a section of plastic. On this section of plastic there are two pieces of felt. Place the Pro.Fit VSM™ just above the lower piece of felt. Using the holes in the mount as a guide, mark three pilot holes with the marking pen. Set the mount aside. Carefully drill three pilot holes using the 5/64" drill bit and drill. Install the phone holder onto the Pro.Fit VSM™. Place the Pro.Fit VSM™ over the three pilot holes. Insert the provided screws and tighten.



STEP 3.

Re-assemble the dash in reverse order securing all nine clips.

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

