



INSTALLATION INSTRUCTIONS

**Dodge Caravan, Plymouth Voyager
Chrysler Town & Country (1994-95)**

PART NUMBER: DG-91-94

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit MOUNT. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Phillips screwdriver, 5/64" drill bit, drill, hook tool.

PARTS INCLUDED: **Pro.Fit** custom mount, one (1) #8x1/2" screw and instructions.

LOCATION: To the left side of climate control.

STEP 1.

Begin by removing trim bezel that surrounds climate control. Insert hook tool in upper right corner of bezel, hooking tool behind bezel, and pulling towards you. Use hook tool on all four corners of bezel to release four (4) clips, two (2) on the top of bezel and two (2) on bottom of bezel. Let bezel hang. **(HINT)** Clips are very tight so pull firmly.



STEP 2.

Using Phillips screwdriver, remove factory screw on left side of climate control. Attach hang-up cup onto **Pro.Fit** mount.



STEP 3.

Position **Pro.Fit** mount over screw hole. Replace and tighten factory screw. With drill and 5/64" drill bit, drill starter hole using **Pro.Fit** mount as a guide. Insert provided screw and tighten with Phillips screwdriver. Reassemble trim bezel.



This completes the installation of your **Pro.Fit** mount.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit** custom mount. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit** International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
Web Address: www.pro-fit-intl.com