



Dodge Journey 2008-2010



DG-92-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screw driver, T20 Torque Driver

PARTS INCLUDED: VSM G3, Lock Plate, J Stem

LOCATION: Right of Radio

STEP 1. Open the cubby box above the air vents. Insert the DTRT between the dash pad and the radio bezel in the lower right hand corner of the radio bezel below the radio. Use a twisting motion with the DTRT to gently release eight (8) clips securing the bezel to the dash pad. Move the bezel off to the side, do not disconnect wiring.



STEP 2. Locate the T20 torque screw securing the upper right side of the radio to the dash pad and remove it. Place the VSM G3 flush and to the right of the radio, exactly in place as pictured in Photo #2. Replace the torque screw over the pilot hole in the leg of the VSM G3 and tighten the VSM G3 evenly and securely in place as pictured.



STEP 3. Once the VSM G3 is flush and secure, place the dash back together again in the reverse order in which it was dismantled. You have successfully installed your VSM G3.



Note: Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com