



Dodge Dakota 2008-2011

DG-92-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screwdriver

PARTS INCLUDED: VSM G3, Lock Plate, J Stem

LOCATION: Right of Radio

STEP 1. Insert the DTRT in the space between the radio/climate control bezel and the dash molding in the upper right hand corner of the bezel just below the air vent. Shown in Photo #1. Use the DTRT in a gentle twisting motion around the radio bezel releasing four (4) retainer clips. Do not disconnect any wiring; simply allow the bezel to hang off to the side.



STEP 2. Locate the Phillips screw securing the upper right side of the radio and carefully remove it. Place the VSM G3 flush to the radio contours as shown in Photo #2. Make sure the pilot hole on the leg of the VSM G3 is flush over the screw hole. Replace the Phillips screw and tighten the VSM G3 in place, making sure that the G3 stays flush and in position.



STEP 3. Replace the bezel carefully back in place. You have successfully installed your VSM G3.



Note: Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ○ ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com