



Dodge RAM 1500 2009-2011
 Dodge RAM 2500, 3500 2010-11
 Ram Chassis Cab 3500, 4500, 5500 2011



DG-92-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), T20 Torque bit and driver, 7mm socket and driver

PARTS INCLUDED: VSM G3, Lock Plate, J Stem

LOCATION: Right of Radio

Step 1: Remove the rubber tray pad in the small tray above the radio to reveal two T20 torque screws. Remove and set them carefully aside. **SPECIAL NOTE FOR 115v PLUG IN OPTION:** If your vehicle has the 115v plug in option, there is another T20 torque screw behind the small plastic trim piece surrounding the plug, **Photo #1**. Use a DTRT to remove this small trim piece and remove the T20 torque screw. Set the screw aside.

Step 2: Place the DTRT in the space between the radio bezel and the dash molding. Use a gentle twisting motion around the entire bezel, releasing a series of 14 retainer clips, **Photo #2**. Once the retainer clips have been released, do not disconnect the wiring to the bezel and simply allow it to hang gently out of the way.

Step 3: Remove the upper rt hand corner bolt securing the right side of the radio to the dash molding. Place the VSM G3 flush to the dash molding and in place just as pictured in **Photo #3**. Replace the 7mm bolt over the VSM G3 and secure it to the dash molding. Be sure to tighten the VSM G3 to the dash.

Step 4: Once the VSM G3 is secure and flush to the dash molding, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!

Note: Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ● ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2009

View Instruction & Updates
 Online at
www.pro-fit-intl.com