



INSTALLATION INSTRUCTIONS

FORD THUNDERBIRD, MERCURY COUGAR (1989-93)

PART NUMBER: FO-56-89

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screw driver.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions.

LOCATION: Right side of console near dash.

STEP 1.

Begin by applying parking brake. Shift into drive. Open arm rest cover and remove the three (3) screws from front top of center console. Carefully lift shift console panel from rear and slide fingers under each side, working towards dash, releasing three (3) clips. Carefully lift and pull back. Do not disconnect wiring. Set aside.



STEP 2.

With the console cover removed, this exposes a horizontal metal bracket at the front of center console. Remove the two (2) screws at the right side of bracket. Loosen two (2) screws on left side.



STEP 3.

Carefully work the **Pro.Fit VSM™** under right side trim, sliding from front to back (small end of mount with two (2) holes.) Slide mount past metal bracket and gently work up to clear plastic. Position the two (2) holes on the **Pro.Fit VSM™** over right side screw holes of metal bracket. Replace and tighten four (4) screws.



STEP 4.

Attach phone hang-up cup to **Pro.Fit VSM™**. Replace console cover and three (3) screws at back.

This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **Pro.Fit International**, Eagan, MN 2003