



INSTALLATION INSTRUCTIONS

FORD AEROSTAR (1993-97)

PART NUMBER: FO-92-93

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 9/32" socket, driver, 5/64" drill bit, drill, Phillips screwdriver.

PARTS INCLUDED: Pro.Fit VSM™, three (3) #8x1/2" screws, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by removing the trim panel below the steering column. To do this, remove three (3) screws below on lower portion of trim panel with 9/32" socket and driver. Pull off trim panel, releasing four (4) clips. Set panel aside. Pull out the ashtray. Behind ashtray, remove two (2) 9/32" hex head screws. Set screws aside.

STEP 2.

Remove trim bezel surrounding the radio, air conditioning vent, ash tray, etc. by pulling and releasing six (6) clips. Do not disconnect wiring. Let hang to the left.

STEP 3.

Align **Pro.Fit VSM™** to right of radio, using centering hole. Using **Pro.Fit VSM™** as a guide, mark three (3) holes for screws. Drill holes using 5/64" drill bit and drill. Insert three (3) 1/2" provided screws and tighten.

STEP 4.

Reinstall trim bezel from around the radio. Reinstall factory screws behind ashtray. Reinstall ashtray. Reinstall trim panel from below the steering panel and three (3) factory screws that hold it in place. Attach hang up cup to **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com