



GPS/Navigation Mounting Adapters

TomTom
Magellan
Mio/Navman



The Adapters below will require a *mount* to be installed into a vehicle. (Not included).
All Pro.Fit International mounts - vehicle specific or universal will work with these adapters.
PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THE GPS ADAPTER

TOOLS REQUIRED: Phillips screw driver, pliers. *Adapters require a vehicle mount.*

CAUTION: It may be helpful to refer to the user manual for directions on how to attach the specific adapter to the back of your GPS unit.

TomTom Easy Port: (TT-22)

Step 1. After selecting the mount required for your vehicle, attach the MG-032 plate to the mount with the hardware provided.
Step 2. Attach the Easy Port adapter to the dbl male t-slot plate. Align the adapters and slide down to lock together.



MG-032



TT-22

Mio/Navman: (NV-1740)

Step 1. After selecting the mount required for your vehicle, attach the 1642 plate to the mount with the hardware provided.
Step 2. Attach the Mio/Navman adapter to the 1642 plate. Align the adapters and slide up or down to lock together.



1642



1740

Magellan 2 Prong: (MG-032)

Step 1. After selecting the mount required for your vehicle attach the MG-032 plate to the mount.



MG-032

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Bracket. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced