



## INSTALLATION INSTRUCTIONS

### HONDA ACCORD (1998-2002)

PART NUMBER: **HO-50-98**

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** #2 Phillips screwdriver, small flat screwdriver.

**PARTS INCLUDED:** Pro.Fit VSM™ mount, instructions.

**LOCATION:** To the right of the radio.

STEP 1. Begin the installation by removing the trim bezel that surrounds the radio. To do this locate two (2) Phillips screws that are underneath the radio holding the trim bezel in place. Remove these screws with your #2 Phillips screwdriver. Set screws aside. Remove the digital clock/emergency flasher module that sits in between the two (2) air vents on the bezel. To do this insert your small flat head screwdriver just below the lower right corner of module. **Carefully** pry upward until clip releases. Do the same in the lower left corner. Grasp the module and pull it out of its cavity. **Disconnect all wiring to the module.** Set module aside.

STEP 2. Locate one (1) Phillips screw that sits behind the clock module and remove it with your #2 Phillips screwdriver. Set screw aside. Grasp the top of the trim bezel with your hands and pull toward you releasing two (2) top clips. Continue working the bezel all the way around releasing the two (2) side clips and two (2) bottom clips. Once the bezel is loose remove all the wiring to the climate control. **NOTE:** The climate control is integrated into the bezel. Set the bezel aside.

STEP 3. Locate and remove four (4) screws holding the radio in place using your #2 phillips screwdriver. Set screws aside. Grasp the radio with your hands and pull out of position. Lift the radio up and set the radio back inside the radio cavity. Let the radio rest inside the cavity. **Do not disconnect wiring to radio.** Locate one (1) gold-colored Phillips screw that is to the right of the radio. Remove this screw with Phillips screwdriver. Install hang-up cup onto Pro.Fit VSM™. Align the hole in the Pro.Fit VSM™ with that screw hole. Insert the gold-colored factory screw and tighten with your Phillips screwdriver.

STEP 4. Replace the radio and four screws that hold it in place. Tighten down radio with Phillips screwdriver. Replace trim bezel in reverse order securing all wiring, clips and screws.

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)

© Pro.Fit International, Eagan, MN 2003