



INSTALLATION INSTRUCTIONS

HONDA CIVIC (1999-2000)

PART NUMBER:HO-52-99

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, Hook Tools, 5/64" drill bit and drill

PARTS INCLUDED: Pro.Fit VSM™, instructions, one (1) #8-3/8" screw

LOCATION: To the right side of radio.

Step 1. Begin by removing the panel directly below the steering column. Remove three (3) Phillips screws located in the upper left, lower left and bottom right corners of the panel. Insert a hook tool directly below the steering column and pull gently towards you to release three (3) retainer clips. Drop the panel down, disconnect the wiring and set the panel aside.



Step 2. Open the glove box. Release the stops on both sides and swing the glove box downward. Next, remove the center panel directly under the radio assembly. There are six (6) Phillips screws holding the panel in place - two (2) on the left side, two (2) in the middle and two (2) on the right side. (See middle picture.) Remove the screws and set the panel aside.



Step 3. Locate and remove four (4) gold, anodized, Phillips, hex-head screws from the bottom side of the radio and air vent assembly. **Caution: The metal edge under the radio assembly is very sharp.** Insert a hook tool between the radio bezel and the dash padding. Move the hook tool around the radio bezel, releasing the retaining clips. Turn the radio to the left as you pull it out, exposing the right side. Locate and remove the factory screw on the right side of the radio assembly. Place the **Pro.Fit VSM™** on the centering pin and reinsert the factory screw. Using the top hole of the Pro.Fit mount as a guide, **carefully** drill a 5/64" pilot hole. Insert the provided 8 x 3/8" screw and tighten. Reassemble the dash in reverse order making sure to reconnect all wiring.



This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit** custom mount. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fax: 651-688-9876
Web Address: www.pro-fit-intl.com