



## INSTALLATION INSTRUCTIONS

HYUNDAI SONATA (1997-98)

(A/T only)

PART NUMBER: **HY-52-97**

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** Hook tool, #2 Phillips screwdriver.

**PARTS INCLUDED:** Pro.Fit VSM™, instructions.

**LOCATION:** Right of the radio.

### STEP 1.

Locate small trim ring surrounding shifter lever on top of shifter lever bezel. Insert hook tool behind ring on front left corner and pull up. Clip will be released. Repeat on front right corner. Slide ring forward and pull up to remove. Set aside. Insert the hook tool behind any corner of the bezel releasing one (1) clip. Repeat on remaining three (3) corners, releasing one (1) clip in each corner. Set bezel aside.



### STEP 2.

**Set emergency brake.** Shift transmission into low gear. Using #2 Phillips screwdriver, locate and remove the Phillips screw located toward bottom of bezel, near ashtray. Set screw aside. Insert hook tool behind upper right corner of radio/climate control trim panel. This bezel also has the cup holder, ashtray & clock intergrated in it. Pull back toward you. Repeat on left side. Grasp panel with your hands and work loose by releasing remaining two (2) clips on bottom. Disconnect all wiring. Set bezel aside.



### STEP 3.

Locate and remove two (2) factory screws on the right side of radio. Set screws aside. Install hang-up cup onto Pro.Fit VSM™. Align Pro.Fit VSM™ with screw holes. Insert and tighten factory screws.



### STEP 4.

Reassemble dash in reverse order securing all clips and screws.

This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)

© Pro.Fit International, Eagan, MN 2003