



INSTALLATION INSTRUCTIONS

HYUNDAI TIBURON (1997-2000)

PART NUMBER: **HY-53-97**

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tool, medium flat-head screwdriver, protective cloth.

PARTS INCLUDED: Pro.Fit VSM™, instructions.

LOCATION: To the right of the radio.

STEP 1. Begin by removing the trim bezel that surrounds the transmission shifter. To do this, wrap the protective cloth around the tip of the flat head screwdriver. **Carefully** insert the flat head screwdriver between the trim bezel and lower section of the center console in the front right corner of bezel. **Carefully** pull upward to release one (1) clip. Perform this same action in the front left corner and right rear corner of bezel releasing a total of two (2) clips. With your **hands** push the rear of the bezel **forward** and **up** to release one (1) **fragile** hook style plastic clip. Perform this same action on the left rear corner of the bezel releasing one (1) more plastic clip. Set bezel aside.

STEP 2. Apply the emergency brake and turn the ignition to the **(on)** position. Shift the transmission into low gear. Insert the hook tool behind the upper left corner of the bezel that surrounds the radio and cubby hole. Pull toward you to release three (3) clips. **NOTE: All three clips should release at the same time.** Insert the hook tool between the trim bezel and the dash just below the climate control in the middle of the bezel. Pull toward you to release two (2) hook style plastic clips. Insert the hook tool in the upper right corner of the trim bezel and pull toward you releasing (2) clips. Grasp the trim bezel and pull it out of its cavity. **NOTE: The ashtray and the cup holder are integrated into the bezel.** Let the bezel hang off to the left side of the center console. **Do not disconnect wiring.**

STEP 3. Locate and remove two (2) screws to the right of the radio using the #2 Phillips screwdriver. Align the holes in the **Pro.Fit VSM™** with the holes to the right of the radio. Insert the two (2) factory screws and tighten.

STEP 4. Re-assemble the dash in reverse order securing all clips. Install your hang up cup onto the **Pro.Fit VSM™**

This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **Pro.Fit International**, Eagan, MN 2003

