



INSTALLATION INSTRUCTIONS

INFINITI Q45 (1994-96)

PART NUMBER: IF-51-94

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Hook tool, #2 Phillips screw drivers, 5/64" drill bit and drill.

PARTS INCLUDED: Pro.Fit VSM™, instructions, one (1) 1/2"x #8 Screw.

LOCATION: To the right of the radio.

STEP 1. Begin by removing the trim bezel surrounding the shifter. Insert the hook tool behind the right rear corner of the trim bezel. Pull upward releasing right rear clip. Perform this same action in the left rear corner. Grasp the bezel and slide it backward toward the rear of the vehicle releasing the front tabs. Disconnect all wiring to the bezel and set bezel aside.

STEP 2. Next, you will be removing the trim bezel that surrounds the radio and climate control. To do this, locate and remove two (2) screws toward the back of the shifter cavity using the #2 Phillips screwdriver. Set screws aside. Locate and remove two (2) screws in the front of the shifter. Set screws aside. Grasp the ashtray and pivot it up to release two (2) trim tabs that are part of the ashtray. Pull the ashtray out of its cavity. Disconnect all wiring to the ashtray and set ashtray aside. Locate and remove two (2) Phillips screws inside the ashtray cavity. Set screws aside. Grasp the trim bezel just to the right of the steering column and pull toward you releasing one (1) clip. Continue pulling toward you releasing three (3) clips along the top of the bezel. Continue working the bezel loose over to the right of the radio releasing one (1) more clip. Disconnect all wiring to the bezel and set the bezel aside.

STEP 3. Using #2 Phillips screwdriver, remove two (2) screws on the right side of the radio. Install the phone holder onto the Pro.Fit VSM™. Install Pro.Fit VSM™ behind the radio mounting bracket in the upper right corner of the radio. Insert the the factory screws and tighten. Using the remaining hole in the Pro.Fit VSM™ as a guide. **Carefully** drill a pilot hole using the 5/64" drill bit and drill. Insert the provided screw and tighten.

STEP 4. Re-assemble the dash in reverse order securing all wiring and clips.

This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003

