



## INSTALLATION INSTRUCTIONS

INFINITI J30 (1993-97)

PART NUMBER: IF-52-93

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

*TOOLS REQUIRED:* Small hook tool, #2 Phillips screwdriver, 5/64" drill bit, and drill.

*PARTS INCLUDED:* **Pro.Fit VSM™**, instructions, one (1) 10x5/8" screw.

*LOCATION:* Right of shifter, between shifter trim panel and center console.

### STEP 1.

Begin by removing the trim bezel that surrounds the shifter. To do this insert the hook tool behind the bezel in the right rear corner. Pull upward to release right rear clip. Perform this same action in the left rear corner of the bezel releasing left rear clip. Grasp the rear of bezel and pivot it upward to release two hook style clips in the front of bezel. **Caution: hook style clips are fragile.** Work the bezel over the shifter knob and set aside.



### STEP 2.

Using a Phillips screwdriver, locate and remove a Phillips screw to the right of the radio toward the front of shifter. This screw holds the radio trim bezel in place. Slide the **Pro.Fit VSM™** under the bezel trim tab. Align the hole in the **Pro.Fit VSM™** with the hole in the trim tab. Insert the factory screw and tighten. Using the remaining hole in the **Pro.Fit VSM™** as a guide, **carefully** drill a pilot hole using the 5/64" drill bit and drill. Insert the provided screw and tighten.



### STEP 3.

Re-assemble the dash in reverse order securing all clips. Install the phone holder onto the **Pro.Fit VSM™**.



This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)

© **Pro.Fit International**, Eagan, MN 2003