



HONDA ODYSSEY (2009-2010)

PART NUMBER: IF-71-03-G3

Page 12



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM-G3.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: DTRT (Dash Trim Removal Tool), 5/64" drill bit & drill, duct tape, 6" phillips screw driver bit with extension driver, utility knife or dremel tool.

PARTS INCLUDED: VSM-G3, two (2) #8 x 5/8" screws, instructions.

LOCATION: Right side of Radio/CD Changer pod.

STEP 1.

Begin by removing trim panel that surrounds the shifter and climate control. Set emergency brake and move shifter into neutral. Using the DTRT (dash trim removal tool) begin by inserting at the passenger end, work clockwise around trim panel, carefully twist to release all clips. Unplug wires and set aside.

STEP 2.

Remove the Radio/CD Changer pod. Remove three (3) phillips screws. Two are in front and one is underneath and deep. *This will require a long extension to access.* Place a protective cloth down, gently pull the radio out. Do not disconnect wires.

STEP 3.

With great care - use a utility knife or dremel to remove the lower half of the rib on the back right side of radio bezel (as marked).

STEP 4.

Position VSM-G3 on the right side of radio cavity as shown. Tape in place. Drill starter holes, then attach with the two (2) screws provided. Carefully reassemble in reverse order.

STEP 5.

Attach your phone holder or electronics to the A Plate and attach to the **VSM-G3 ball**. The J Stem is optional for repositioning your electronics to your liking. This completes the installation of your **Pro.Fit VSM-G3**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM©. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2009

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM