



## INSTALLATION INSTRUCTIONS

**JAGUAR XJ6 Sedan (1988-94)**

**PART NUMBER: JG-50-88**




---

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

---

**Pro.Fit logo and part number will be right side up and readable when installed.**

*TOOLS REQUIRED:* Phillips screw driver, 8mm box end wrench

*PARTS INCLUDED:* **Pro.Fit VSM™**, instructions.

*LOCATION:* Right, front side of Center Console.

---

### STEP 1.

Begin by opening center arm rest and removing two (2) screws at front securing ash tray. Remove ash tray. Remove trim surrounding shifter. (Plastic ring is fragile.) With palm up, slide hand in opening and remove wing nuts. **CAREFULLY** lift console panel from back and slide back to remove. Carefully set aside.

### STEP 2.

Within the right side of console, locate the 8mm nut which secures passenger seat controls. Loosen, but do not remove.

### STEP 3.

Attach phone hang-up cup to **Pro.Fit VSM™**. Position **Pro.Fit VSM™**, sliding "T" slot down onto stud (with loosened nut) and slide mount to desired position. The phone should hang to the right of center console. Tighten nut securing **Pro.Fit VSM™** in place. **CAREFULLY** reposition console panel. Replace and tighten securing wing nuts.

### STEP 4.

Replace trim around shifter, and replace ash tray and two (2) screws in front arm rest area.

This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

**Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)**