



INSTALLATION INSTRUCTIONS

**XJ6 (1995-97)
JAGUAR XJR, VANDEN PLAS (sedan only) (1995-97)**

PART NUMBER: JG-50-95

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Small flat screwdriver, # 2 Phillips screwdriver, marking pen, 5/64" drill bit, drill.

PARTS INCLUDED: Pro.Fit VSM™, three #8x3/4" screws, instructions.

LOCATION: Front right side of center console.

STEP 1.

Begin by opening center arm rest and removing two (2) Phillips screws at front securing ashtray. Remove ashtray. Using fingers pull up on and remove black plastic trim ring surrounding shifter. **(CAUTION: PLASTIC TRIM PIECE IS VERY FRAGILE)** Disconnect wiring harness from plastic trim ring and set aside. Using small flat head screwdriver remove silver trim ring that holds shifter pod in place. Place small screwdriver in between shifter pod and silver trim ring on all four corners and release four (4) clips. **(CAUTION: CLIPS ARE VERY FRAGILE)**. Set silver trim ring aside. Remove pod and set aside. With palm up, slide hand in opening and remove two (2) wing nuts. Set wing nuts aside. **CAREFULLY** lift console panel from back and slide backward to remove. Carefully set aside.



STEP 2.

Locate a flat ridge section on the right side of the center console. Position Pro.Fit VSM™ over this section, placing mount as close to the front toward the dash as your phone will allow. Using the Pro.Fit VSM™ as a guide, mark three (3) holes. Set Pro.Fit VSM™ aside. Drill pilot holes with 5/64" drill bit and drill.



STEP 3.

Reposition Pro.Fit mount over pilot holes. Insert and tighten provided screws. Attach hang-up cup onto Pro.Fit VSM™. **CAREFULLY** replace all parts in reverse order.

This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003