



JAGUAR XK8 (1997-2006) JAGUAR XKR (1997-2006)

PART NUMBER: **JG-51-97**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 2 Phillips screwdriver, small flat head screwdriver, marking pen, 5/64" drill bit, drill.

PARTS INCLUDED: Pro.Fit VSM®, three (3) #8x3/4" screws, instructions.

LOCATION: Right front side of center console.

STEP 1.

(CAUTION) The four (4) clips that are part of the plastic trim ring bezel that surrounds shifter lever are very fragile and can break if not careful taking it off.

Begin by removing plastic trim ring bezel which surrounds shift lever. Using a small flat head screwdriver locate first clip that sits in the lower right corner of bezel. The clip is located between the trim bezel and shifter pod. Set small flat head screwdriver in between the seam of the bezel and shifter pod to release clip. Do the same on all four corners of the trim ring bezel.



STEP 2. Using # 1 Phillips screwdriver, locate and remove four (4) screws and two (2) metal retainers which are holding wood grain trim panel in place. Set screws and retainers aside. Pull up and out on wood grain trim bezel panel to remove.



STEP 3.

Install hang up cup onto Pro.Fit VSM®. On the right wall of console, locate the ledge in which the wood grain trim bezel rested. Set Pro.Fit VSM® as far forward on this ledge as your phone will allow. Mark holes. Set Pro.Fit VSM® aside. Drill pilot holes using 5/64" drill bit and drill. Reposition Pro.Fit VSM® over pilot holes. Insert and tighten screws provided with Pro.Fit VSM®.



STEP 4.

Reinstall all parts in reverse order.

This completes the installation of your Pro.Fit VSM®.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

