



## INSTALLATION INSTRUCTIONS

**KIA SPORTAGE (1999-2000)**  
(A/T only)

PART NUMBER: **KA-70-99**

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** Hook tool, #1 Phillips screwdriver, masking tape.

**PARTS INCLUDED:** Pro.Fit VSM™, instructions.

**LOCATION:** To the right of the climate control.

**STEP 1.** Begin by inserting the hook tool behind the bezel that surrounds the radio and climate control in the lower right corner of the bezel. Carefully pull toward you to release the lower right clip. Carefully grasp the bottom section of the bezel and pull toward you releasing two more bottom clips. Grasp the bezel on both the left and right sides toward the bottom. Carefully pull toward you to release two lower side clips. Insert the hook tool behind the bezel in the upper right corner. Pull toward you to release the top right clip. Perform this same action in the upper left corner of the bezel. There are a total of seven clips holding the bezel in place. Once the bezel is loose, disconnect all wiring to the bezel and set it aside.

**STEP 2.** Locate the two screws that hold the climate control in place on the right side. Remove the screws with the #1 Phillips screwdriver. Place the **Pro.Fit VSM™** over these two screw holes aligning both holes. Insert the two factory screws and tighten. **NOTE:** Use the access holes on the face of the mount by inserting the screwdriver through the holes to tighten the screws.

**STEP 3.** Place a small piece of masking tape in the top right inside corner of the bezel opening for the climate control. This is to protect the bezel from being scratched. Replace the bezel by carefully sliding it over the **Pro.Fit VSM™** through the opening for the radio and climate control. Reconnect all wiring to the bezel and secure all seven clips. Remove the masking tape. Install the phone holder onto the **Pro.Fit VSM™**.

This completes the installation of your **Pro.Fit VSM™**.



**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

**Web Address:** [www.pro-fit-intl.com](http://www.pro-fit-intl.com)

© **Pro.Fit International**, Eagan, MN 2003