



Nissan Sentra 2007-2008

NS-54-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of Climate Control

STEP 1. Apply the parking brake and set the transmission in neutral. Insert the DTRT between the shifter bezel and the dash molding just as pictured in Photo #1. Use the DTRT in a gentle twisting motion around the shifter bezel in order to release a series of retainer clips. Do NOT remove the shifter knob and bezel; simply allow enough room to clear the climate control bezel from the tongue and groove joint connecting the two bezels.



STEP 2. Once the shifter bezel is out of the way, insert the DTRT between the dash molding and the climate control bezel. Use the DTRT again in a twisting motion to release a series of four (4) retainer clips securing the climate control bezel to the dash. Do NOT disconnect the climate control wiring; simply allow the bezel to hang off to the side out of the way.



STEP 3. Place the VSM G3 in position exactly as pictured in Photo #2. Make sure it is position just below the retainer clip hole and is as snug and flush to the dash molding as possible. Once it is in position, use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Carefully drill out the marked locations with a 5/64" bit and drill. DO NOT drill more than 1/4" deep! Place the VSM G3 over the pilot holes and tighten it flush to the dash with the two provided #8X1/2" screws and a Phillips screw driver.



STEP 4. Place the dash together in the reverse way in which it was dismantled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com