



**INSTALLATION INSTRUCTIONS**  
**PONTIAC BONNEVILLE (1995-99)**  
**PART NUMBER: PT-50-95**

**VIEW INSTRUCTIONS & UPDATES  
 ONLINE @  
 WWW.PRO-FIT-INTL.COM**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.** All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

*TOOLS REQUIRED:* #1 Phillips screwdriver.

*PARTS INCLUDED:* **Pro.Fit VSM™**, instructions.

*LOCATION:* To the right of the climate control.

**STEP 1.**

Begin by removing the trim bezel surrounding the radio and climate control unit. This bezel extends from the right of the steering column to the right of the radio and climate control unit. Start on the right side of the steering column, grasp bezel and pull with fingers to release first retainer clip. Continue working around bezel till all 6 retainer clips are released. Set bezel aside.



**STEP 2.**

Locate and remove two (2) screws to the right of the climate control unit.



**STEP 3.**

Install hang-up cup onto **Pro.Fit VSM™**. Install **Pro.Fit VSM™** behind climate control mounting bracket, aligning with holes and centering pin. Reinsert and tighten factory screws. Reinstall trim bezel.



This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876  
**Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)**