



**INSTALLATION INSTRUCTIONS**  
**PONTIAC GRAND PRIX (1997-2003)**  
**(center console shift only)**  
**PART NUMBER: PT-51-97**

**VIEW INSTRUCTIONS & UPDATES  
 ONLINE @  
 WWW.PRO-FIT-INTL.COM**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

*TOOLS REQUIRED:* 9/32" socket and ratchet.

*PARTS INCLUDED:* **Pro.Fit VSM™** and instructions.

*LOCATION:* To the right of the radio

**STEP 1.**

Begin by loosening the trim panel located underneath the steering column. Using the ratchet and 9/32" socket, remove the two (2) screws directly underneath the panel, one on each side of the steering wheel holding two (2) tabs. Grasp the top section of the panel and pull toward you releasing the two (2) top clips on both sides of the steering wheel. **NOTE:** The trim panel does not need to be removed, just loosened. Let the panel hang.



**STEP 2.**

Remove the dash trim bezel by releasing eleven (11) clips: four (4) above, five (5) below and two (2) on the sides. **CAUTION: The clips can be very tight and may come loose and can fall behind the dash.** Do this by carefully pulling on the left side of the trim bezel, pulling to release clips as you work your way to the right side of the bezel. Disconnect all wiring to the bezel and remove completely. Attach the phone holder onto the **Pro.Fit VSM™**. Remove the 9/32" screw to the right of the radio. Slide the **Pro.Fit VSM™** behind the radio mounting bracket, aligning it with the centering pin. Re-insert and tighten the factory screw.



**STEP 3.**

Re-assemble the dash securing all clips and screws



This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

**Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)**