



**Pontiac TransAm (1994-2002)**  
**Pontiac Firebird (1994-2002)**

**PART NUMBER: PT-52-94**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.**  
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** 9/32" socket, driver, # 2 Phillips screw driver, 5/64" drill bit, drill, hook tool.

**PARTS INCLUDED:** Pro.Fit VSM®, one (1) # 8 x 1/2" screw, instructions.

**LOCATION:** Right of radio

**STEP 1.**

Begin by removing climate control and radio trim bezel, by inserting hook tool behind bezel in lower left corner . Pull to release clips repeating on all four corners of trim bezel, set bezel aside.



**STEP 2.**

Using 9/32" socket, remove factory screw to the right of the radio. Attach hang-up cup onto Pro.Fit VSM®. Place Pro.Fit VSM® over radio mounting bracket. Reinstall factory screw and tighten. Drill starter hole with 5/64" drill bit. Insert and tighten provided screw.



**STEP 3.**

Replace trim panel by aligning and inserting clips back into place.



This completes the installation of your Pro.Fit VSM®.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

