



## INSTALLATION INSTRUCTIONS

PONTIAC GRAND AM (1996-98)

PART NUMBER: **PT-53-97**

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** Short #2 Phillips screwdriver, standard #2 Phillips screwdriver, #15 Torx driver.

**PARTS INCLUDED:** Pro.Fit VSM™ and instructions.

**LOCATION:** To the right of the radio.

### STEP 1.

Locate and remove two (2) Phillips screws above the instrument cluster using the #2 short Phillips screwdriver. Set screws aside. Just below the climate control unit inside cubby hole locate and remove two (2) additional screws that hold the dash trim bezel in place using the standard Phillips screwdriver. **NOTE: On vehicles with the optional cassette player, remove the bezel that surrounds the player by grasping the front of the bezel and pull toward you to release two (2) clips. Remove two (2) Phillips screws above the cassette player. Set screws aside. Grasp the cassette player and pull it out of the cubby hole. Disconnect all wiring to the cassette player and set it aside. At this point you can locate and remove the two (2) additional screws inside the cubby hole that hold the dash trim bezel.**



### STEP 2.

Grasp the dash trim bezel to the left side of the steering column by the driver's side door and pull toward you releasing a series of six (6) clips. Work the bezel loose all the way over to the radio, just enough to gain access to the Torx screw to the right of the radio. **NOTE: There is no need to remove the bezel completely.** Remove the Torx screw with Torx driver. Place the Pro.Fit VSM™ over the screw hole, aligning that hole and the hole for the centering pin. Replace the factory Torx screw and tighten.



### STEP 3.

Re-assemble the dash in reverse order securing all wiring, clips, and screws. Install the phone holder onto the Pro.Fit VSM™.



This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)