



## INSTALLATION INSTRUCTIONS

### PONTIAC SUNFIRE (1997-99)

PART NUMBER: **PT-54-97**

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.** All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** Short #2 Phillips screwdriver, #10 Torx screwdriver, 9/32" open end wrench.

**PARTS INCLUDED:** Pro.Fit VSM™, instructions.

**LOCATION:** To the right of the radio.

#### STEP 1.

Begin by opening glove compartment. Locate two (2) Phillips screws to the right of the radio that are holding the trim bezel in place. Using Phillips screwdriver, remove screws and set aside. Slide trim bezel towards glove box to release guide pins on left of side of bezel. Set bezel aside.



#### STEP 2.

Locate Torx head screw on the right side of the radio and remove, using the Torx driver. Place **Pro.Fit VSM™** over hole and centering pin. Using 9/32" wrench, reinsert and tighten screw.



#### STEP 3.

Replace radio trim bezel. Re-insert factory screws and tighten. Attach hang-up cup onto **Pro.Fit VSM™**.



This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

**Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)**