



INSTALLATION INSTRUCTIONS

SAAB 9000 (1997-98)

PART NUMBER: **SB-50-97**

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Stub Phillips screwdriver, DIN tools, marking pen, 5/64" drill bit, drill.

PARTS INCLUDED: **Pro.Fit VSM™**, three (3) #6x1/2" bevel head self tapping screws,
instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by bending **DIN** tools into an "L" shape. **(This is Saab's radio removal method. They do not produce a tool for radio removal.)** Insert one end of each **DIN** tool into the two (2) holes in the radio. Apply outward pressure to **DIN** tools and pull back to remove radio. Let radio hang out of way.

STEP 2.

On the trim bezel, to the right of the radio, locate a flat surface. **Pro.Fit VSM™** will be mounted between this flat surface and the radio. Place **Pro.Fit VSM™** on this flat surface, all the way back in bezel cavity. With marking pen, mark three (3) holes using **Pro.Fit VSM™** as a guide. Set **Pro.Fit VSM™** aside. Drill starter holes.

STEP 3.

Attach hang-up cup onto **Pro.Fit VSM™**. Reposition the **Pro.Fit VSM™** over holes. Insert and tighten screws provided with **Pro.Fit VSM™**. Make sure screw heads are flush with the surface of the **Pro.Fit VSM™** to allow clearance for the radio to fit properly.

STEP 4.

Re-install radio.

This completes the installation of your **Pro.Fit VSM™**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
Web Address: www.pro-fit-intl.com