



INSTALLATION INSTRUCTIONS

SATURN (1995-99)

PART NUMBER: **ST-50-95**

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 5/64" drill bit, drill, 9/32" socket & ratchet, # 2 Phillips Screwdriver.

PARTS INCLUDED: **Pro.Fit VSM™**, instructions, three (3) #8x1/2" screws.

LOCATION: Upper left corner of glove box.

STEP 1.

Begin by opening glove box door. Remove glove box door by turning locking mechanisms inside on left and right sides of glove box. The Pins will drop out. **Carefully** lower the glove box door down. With 9/32" socket and ratchet, remove six (6) bolts [one (1) at top of right side, one (1) at top of left side, two (2) inside towards back, and two (2) by locking mechanism located inside glove box.]



STEP 2.

Grasp the black plastic inner shell and pull downward to release two (2) clips located to the left of left and right of right rubber bumpers. Tray will drop out.



STEP 3.

Install hang up cup on **Pro.Fit VSM™**. Insert **Pro.Fit VSM™** into cubby hole to the left of clip on left side. Hold tightly in place. Using the **Pro.Fit VSM™** as a guide, drill three (3) pilot holes with 5/64" drill bit and drill. Insert provided screws and tighten with #2 Phillips screwdriver. Re-install glove box parts.



This completes the installation of your **Pro.Fit VSM™**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
Web Address: www.pro-fit-intl.com