



## INSTALLATION INSTRUCTIONS

TOYOTA CAMRY (1992-96)

PART NUMBER: TY-50-92

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

*TOOLS REQUIRED:* #2 Phillips screwdriver, hook tool.

*PARTS INCLUDED:* **Pro.Fit VSM™**, instructions.

*LOCATION:* To the right of the radio.

### STEP 1.

Begin by removing the trim bezel surrounding the radio. To do this, insert hook tool between the console dash and the trim bezel at the bottom right and left corners. Bezel will release. Do not disconnect cigarette lighter wiring harness. Lay trim bezel to side.



### STEP 2.

Remove the radio mounting screw on the right side of radio. Attach the phone hang-up cup onto **Pro.Fit VSM™**.



### STEP 3.

Position **Pro.Fit VSM™** over centering pin and screw hole. Insert and tighten factory screw.



### STEP 4.

Reinstall radio trim bezel back into position.

This completes the installation of your **Pro.Fit VSM™**.

**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM™**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation.

**Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

**Web Address:** [www.pro-fit-intl.com](http://www.pro-fit-intl.com)

© **Pro.Fit International**, Eagan, MN 2003