



INSTALLATION INSTRUCTIONS

TOYOTA CELICA (1997-99)

PART NUMBER: **TY-53-97**

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Hook tool, #1 Phillips screwdriver, 5/64" drill bit, drill.

PARTS INCLUDED: Pro.Fit VSM™, one (1) #8x3/8" self tapping screw, instructions.

LOCATION: Right of the radio/cassette player.

STEP 1.

Begin by applying parking brake. Place transmission into low gear. Using the hook tool, insert behind bezel which surround the shifter and pull up to release clips. There are two (2) clips on the left and two (2) on the right which need to be released. Set bezel aside.

STEP 2.

Locate and remove two (2) screws located on the bottom of the radio trim bezel. Set aside. Using the interior hook tool, insert behind the radio trim bezel on bottom right and pull back to release side clips. Using fingers, pull on bezel to release remaining three (3) clips. Wiring does not need to be disconnected. Let bezel hang to the left side.

STEP 3.

Locate and remove two (2) screws to the right of the radio. Pull radio out just enough to insert Pro.Fit VSM™ behind the radio mounting bracket, aligning it with the bottom screw hole and centering pin. Reinsert factory screws and tighten. Using 5/64" drill bit and drill, drill starter hole using remaining hole in Pro.Fit VSM™ as a guide. Insert and tighten provided screw.

STEP 4.

Reinstall radio trim bezel back into position. Reinsert and tighten factory screws. Reinstall shifter bezel back into position. Attach hang-up cup onto Pro.Fit VSM™. Place transmission in park. Release parking brake..

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003