



INSTALLATION INSTRUCTIONS

TOYOTA CAMRY SOLARA (1999-2003)

PART NUMBER: TY-55-99

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS PRO-FIT MOUNT.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

PRO-FIT logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: 10mm socket and driver, hook tool.

PARTS INCLUDED: **PRO-FIT** custom mount, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by removing the bezel that surrounds the radio and climate control. This bezel also has two air vents integrated into it above the radio. Remove the ashtray and set it aside. Grasp the lower section of the bezel inside the ashtray cavity and carefully pull toward you to release the lower left bottom clip. To release the lower right clip, insert the hook tool behind the bezel to the right of the cigarette lighter. Carefully pull toward you to release.

STEP 2.

Grasp the bezel with both hands. Pull toward you releasing two clips on the right and left sides of the radio and climate control. Grasp the top of the bezel just above the air vents. Carefully pull toward you to release two more clips located above the air vents. When all ten (8) clips are released, disconnect all wiring to the bezel. Set the bezel aside.

STEP 3.

Using the 10mm socket and driver, locate and remove the top right screw that holds the radio in place. Install the phone holder onto the **PRO-FIT** mount. Place the **PRO-FIT** mount over the screw hole aligning both holes. Insert the 10mm factory screw and tighten.

STEP 4.

Re-assemble the dash in reverse order securing all wiring and clips.

This completes the installation of your **PRO-FIT** mount.



PRO-FIT International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **PRO-FIT** custom mount. **PRO-FIT** may not be held liable for any personal injury resulting from accident or improper installation.

PRO-FIT International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© **PRO-FIT** International, Eagan, MN 2000