



MANUAL CLIMATE CONTROL ONLY

**TOYOTA TUNDRA (2000-2005)
TOYOTA SEQUOIA (2001-2004)**

(See reverse side for Automatic Climate Control)

PART NUMBER: TY-71-00

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tools, 5/64" drill bit and drill, marking pen.

PARTS INCLUDED: Pro.Fit VSM®, instructions, two (2) #8x1/2" screws.

LOCATION: Right of air vent.

STEP 1. Locate the two air vents that are on the right and left sides of the radio. Remove both of these air vents by inserting the hook tool between the vents and the bezel and carefully prying outward on the vents to remove. Set the vents aside. Inside the vent cavities locate and remove two (2) Phillips screws using the Phillips screwdriver. Set the screws aside.

STEP 2. Locate the three knobs that are on the climate control. Grasp the knobs and carefully pull toward you to remove. Set the knobs aside. Locate and remove the three (3) Phillips screws that are behind the knobs. Set the screws aside. Grasp the top middle section of the bezel just above the radio and carefully pull towards you releasing the top clip. Insert both your hands into the air vent cavities. Grasp the bezel and pull toward you to release a series of six clips that are behind and attached to the back of the climate control. These clips hold the lower section of the bezel in place. When the bezel is loose **do not disconnect any wiring.** Let the bezel hang.


STEP 3. Locate the flat section of plastic to the right of the right air vent, (See middle picture). Place the **Pro.Fit VSM®** over this section of plastic, making sure that the bottom of the **VSM®** is level. Once the **VSM®** is in position, mark two (2) spots for drilling pilot holes using the two (2) holes in the **Pro.Fit VSM®** as a guide. Set the mount aside. Carefully drill two (2) pilot holes using the 5/64" drill bit & drill, **making sure to not drill too deep!** Place the **Pro.Fit VSM®** over the two pilot holes. Insert the two (2) provided screws and tighten.

STEP 4. Re-assemble the dash in reverse order securing all screws and clips. Install the phone holder onto the **Pro.Fit VSM®**.

This completes the installation of your **Pro.Fit VSM®**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2004





AUTOMATIC CLIMATE CONTROL ONLY

TOYOTA TUNDRA (2000-2005)

TOYOTA SEQUOIA (2001-2004)

(See reverse side for Manual Climate Control)

PART NUMBER: TY-71-00

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®. All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tools, 5/64" drill bit and drill, marking pen.

PARTS INCLUDED: Pro.Fit VSM®, instructions, two (2) #8x1/2" screws.

LOCATION: Right of air vent.

STEP 1. Push the top of the left and right air vents into the dash, exposing two (2) Phillips screws, (See top picture). Remove the screws. There are five (5) retainer clips that hold the radio bezel in place. They are located at top center, left and right middle and the remaining two (2) on the bottom of the bezel. Using a thin, flat screwdriver, carefully pry off the radio bezel. Set the bezel aside.



STEP 2. Locate the flat section of plastic to the right of the right air vent, (See middle picture). Place the **Pro.Fit VSM®** over this section of plastic, making sure that the bottom of the **VSM®** is level. Once the **VSM®** is in position, mark two (2) spots for drilling pilot holes using the two (2) holes in the **Pro.Fit VSM®** as a guide. Set the mount aside. **Carefully** drill two (2) pilot holes using the 5/64" drill bit & drill, **making sure to not drill too deep!** Place the **Pro.Fit VSM®** over the two pilot holes. Insert the two (2) provided screws and tighten.




STEP 3. Re-assemble the dash in reverse order securing all screws and clips. Install the phone holder onto the **Pro.Fit VSM®**.



This completes the installation of your **Pro.Fit VSM®**.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2004

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**