



INSTALLATION INSTRUCTIONS

TOYOTA RAV4 (1996-2000)

PART NUMBER: TY-73-97

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #1 Phillips screwdriver

PARTS INCLUDED: Pro.Fit VSM™ and Instructions.

LOCATION: Right of the radio

STEP 1.

Begin by removing radio trim bezel which is a separate piece surrounding radio. To do this, locate and remove two (2) Phillips screws located directly under radio. Grasp top portion of bezel, pulling down and out. This will release two (2) tabs. Set bezel aside.



STEP 2.

Remove screw to the right of the radio, directly above the centering pin.



STEP 3.

Attach hang-up cup onto the Pro.Fit VSM™. Install Pro.Fit VSM™, aligning it over the screw hole to the right of the radio and the centering pin. Insert and tighten screw. Reattach radio trim bezel.



This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876
www.pro-fit-intl.com