



INSTALLATION INSTRUCTIONS

TOYOTA PREVIA (1991-96)

PART NUMBER: TY-90-91

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, 5/64" drill bit, drill, marking pen.

PARTS INCLUDED: Pro.Fit VSM™, three (3) #8x3/8" self-tapping screws, instructions.

LOCATION: To the right of the right air duct.

STEP 1.

Remove door cover located on top of the climate control and radio dash pod. To do this, locate the latch just above air-conditioning switch on climate control. With your finger press up on latch. This will loosen cover. Grasp cover with both hands and slide it to the left of the dash pod. Let cover rest on top of dash.



STEP 2.

Inside dash pod locate the fuse box. Directly to the right of fuse box locate a long flat spot that is part of the dash pod. Set Pro.Fit VSM™ in place, checking to make sure door cover will close properly after installation. Using Pro.Fit VSM™ as a guide, mark holes with marking pen. Set Pro.Fit VSM™ aside. Drill pilot holes using 5/64" drill bit and drill in marked positions. Align Pro.Fit VSM™ with pilot holes. Using #2 Phillips screwdriver insert and tighten provided screws.



STEP 3.

Re-attach door cover. Install hang-up cup onto Pro.Fit VSM™.

This completes the installation of your Pro.Fit VSM™.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com

© Pro.Fit International, Eagan, MN 2003