



## Dodge Ram 1500, 2500, 3500 (2002-2008)

PART NUMBER: **DGANTPF**

(For NMO style antenna mount)

Please Read Complete Instructions Before Installing This Pro.Fit Antenna Mount

**TOOLS REQUIRED:** 10 mm socket and driver or 10 mm box end wrench

**PARTS INCLUDED:** Pro.Fit Antenna Mount, 1/2" stainless steel star washer, instructions

**LOCATION:** Left Front Fender

**Please read** Always check for good continuity between antenna mount and chassis ground. If there is a problem with grounding, place the provided star washer between the NMO antenna mount and vehicle's fender.

### STEP 1.

Set parking brake. Open hood and locate 10 mm bolt near the back of the left front fender. Remove bolt.

### STEP 2.

Align the antenna bracket with the bolt hole. Reinstall bolt and tighten.


### STEP 3.

Install NMO antenna mount on bracket. (NMO not supplied).

This completes the installation of your **Pro.Fit** Antenna Mount for NMO style antenna.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2006

VIEW INSTRUCTIONS & UPDATES  
ONLINE @  
[WWW.PRO-FIT-INTL.COM](http://WWW.PRO-FIT-INTL.COM)