



Toyota Tundra 2007-2008

PART NUMBER: TYANTPF
(For NMO style antenna mount)

Please Read Complete Instructions Before Installing This Pro.Fit Antenna Mount

TOOLS REQUIRED: 10mm socket and driver

PARTS INCLUDED: Pro.Fit Antenna Mount, 1/2" stainless steel star washer, instructions

LOCATION: Left Front Fender

Please read Always check for good continuity between antenna mount and chassis ground. If there is a problem with grounding, place the provided star washer between the NMO antenna mount and vehicle's fender.

STEP 1: Set parking brake. Open hood and locate the 10mm bolt near the back of the left front fender. Remove bolt.

STEP 2: Align the antenna bracket with the bolt hole. Reinstall bolt and tighten.

STEP 3: Install NMO antenna bracket. (NMO not supplied)

This completes the installation of your Pro.Fit International antenna mount for your NMO style antenna.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2006

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM