



**AMIGO (1998-2004)
ISUZU RODEO (1998-2004)
HONDA PASSPORT(1998-2001)**

PART NUMBER: IZ-71-98

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: #2 Phillips screwdriver, hook tool.

PARTS INCLUDED: Pro.Fit VSM™, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by applying the emergency brake. Turn the ignition to the “on” position and put transmission into neutral. Remove the ashtray by simultaneously pulling out and up. Set ashtray aside. Locate the Phillips screw inside empty ashtray cavity. Remove screw with your #2 Phillips screwdriver. Set screw aside.

STEP 2.

Remove the trim bezel that surrounds the radio by inserting hook tool in the upper right corner of radio behind the trim bezel. Pull toward you to release the first clip. Perform this same action in the upper left corner of the bezel. Once the two (2) top clips are released grasp the bezel with both hands on the left and right sides. Pull toward you to release two (2) more clips. Do the same on the bottom of the bezel releasing the two (2) bottom clips. Disconnect all wiring to the bezel. Set bezel aside.

STEP 3.

Locate two (2) Phillips screws to the right of the radio. Remove the top screw with your #2 Phillips screwdriver. Align the top hole in the Pro.Fit VSM™ with the top right screw hole. Insert the Phillips factory screw and tighten.

STEP 4.

Re-assemble the dash in reverse order securing all clips and wiring. Install the phone holder onto the Pro.Fit VSM™.

This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

