



ACURA INTEGRA (1994-2001)

PART NUMBER: AC-53-94

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Phillips screwdriver.

PARTS INCLUDED: **Pro.Fit VSM®**, instructions.

LOCATION: To the right side of ashtray.

STEP 1.

Begin by removing rubber gasket around shifter. Remove plastic trim ring by pulling up to release. Remove center console. Remove small cover under emergency brake arm. Remove two (2) screws under cover. Remove two (2) screws located at the back of console on each side. Remove one (1) screw on each side of front of console. Remove one (1) screw on each side of front section of console, down near your feet.

STEP 2.

Apply emergency brake. With handle pulled up, shift transmission into first gear or low. Carefully remove console. Remove ashtray and cigarette lighter unit. Remove two (2) outer screws toward back of unit. Carefully pull out, releasing clips. Be careful of the two (2) clips securing unit as they can easily fall out. Disconnect wiring harness to ashtray.

STEP 3.

Remove two (2) screws in upper corners of ashtray cavity. Carefully remove front section of console. Just above cup holder at right, remove screw. Attach hang-up cup onto the **Pro.Fit VSM®**. Position **Pro.Fit VSM®** into wedge, replace screw just above cup holder. (Mount will also be secured by screw in upper right corner of ashtray cavity.) Replace front section of console and screws.

STEP 4.

Reconnect wiring harness to ashtray and slide back into position. Replace center console and screws. Replace plastic trim ring around shifter and rubber gasket.

This completes the installation of your **Pro.Fit VSM®**.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

